





BRICK VENEER

INSULATION, IDENTIFY TYPE AND LOCATION

QUICK GRIP ADHESIVE

WALL TIE, FASTENER HOLE SEALED AND TOOLED WITH POLYGUARD AIRLOK DETAIL-N-JOINT OR DETAIL SEALANT PW BETWEEN BACK OF WALL TIE AND AIR BARRIER FIELD MEMBRANE

POLYGUARD AIRLOK SPRAY-N-ROLL OR AIRLOK FLASH-N-ROLL FLUID-APPLIED AIR BARRIER MEMBRANE. APPLY AIR BARRIER BEFORE (AS SHOWN) OR AFTER SELECTED FLASHING.

**GYPSUM SHEATHING** 

METAL STUD FRAMING

TERMINATION BAR (BY OTHERS) FOR SHEET THRU-WALL FLASHING ONLY. APPLY AND TOOL WITH POLYGUARD DETAIL SEALANT PW OR AIRLOK DETAIL-N-JOINT ALONG TOP EDGE AND OVER EACH FASTENER HEAD. TERMINATION BAR AND SEALANT ARE NOT REQUIRED IN COMBINATION WITH FLUID-APPLIED THRU-WALL FLASHING MATERIALS.

POLYGUARD AIRLOK GUN-N-SPREAD, AIRLOK FLASH-N-ROLL, AIRLOK DETAIL-N-JOINT, OR DETAIL SEALANT PW TOOLED TO 25 MILS WET; OR POLYGUARD AIRLOK SHEET 200 BU / NP, AIRLOK SHEET 400 NP, OR AIRLOK SHEET 400 HT / NP APPLIED OVER POLYGUARD 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT APPLIED AT A RATE OF 250 - 300 SF / GAL. OR OVER 650 WB LIQUID ADHESIVE APPLIED AT A RATE OF 350 - 400 SF / GAL: OR APPLIED OVER QUICK GRIP SPRAY ADHESIVE. EXTEND SELECTED FLASHING MEMBRANE A MINIMUM 3" ONTO AIR BARRIER MEMBRANE AND TERMINATE 5/8" FROM BEND IN DRIP EDGE (END DAMS NOT SHOWN). APPLY SELECTED FLASHING MATERIAL EITHER BEFORE OR AFTER (AS SHOWN) SELECTED POLYGUARD AIR BARRIER MEMBRANE.

CONNECTION BETWEEN FLOOR PLATE AND SHELF ANGLE PER ENGINEERING DETAILS

3/4" CANT OF POLYGUARD DETAIL SEALANT PW OR DETAIL-N-JOINT APPLIED AND TOOLED ALONG SELECTED AIR BARRIER MEMBRANE AND SHELF ANGLE JOINT

STAINLESS STEEL OR COPPER DRIP EDGE

COMPRESSIBLE PAD

LIP BRICK

POLYGUARD AIRLOK GUN-N-SPREAD, AIRLOK FLASH-N-ROLL, AIRLOK DETAIL-N-JOINT, OR DETAIL SEALANT PW TOOLED TO 25 MILS WET; OR POLYGUARD AIRLOK SHEET 200 BU / NP, AIRLOK SHEET 400 NP, OR AIRLOK SHEET 400 HT / NP APPLIED OVER POLYGUARD 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT APPLIED AT A RATE OF 250 - 300 SF / GAL, OR OVER 650 WB LIQUID ADHESIVE APPLIED AT A RATE OF 350 -400 SF / GAL; OR APPLIED OVER QUICK GRIP SPRAY ADHESIVE. EXTEND SELECTED FLASHING MEMBRANE A MINIMUM 3" ONTOTHE AIR BARRIER MEMBRANE. APPLY SELECTED FLASHING MATERIAL EITHER BEFORE OR AFTER (AS SHOWN) SELECTED POLYGUARD AIR BARRIER MEMBRANE.

POLYGUARD AIRLOK SPRAY-N-ROLL OR AIRLOK FLASH-N-ROLL FLUID-APPLIED AIR BARRIER MEMBRANE. APPLY AIR BARRIER BEFORE (AS SHOWN) OR AFTER SELECTED FLASHING.

02

SECTION @ FRAMED BACKING WALL / MASONRY VENEER - FLOOR TRANSITION

**STPE** 

SOME MATERIALS SEPARATED FOR CLARITY

Polyguard Products, Inc. P.O. Box 755 - Ennis, TX 75120 Phone: 214-515-5000 Web Site - www.polyguard.com

The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.

© POLYGUARD PRODUCTS, INC.

NOT TO SCALE EFFECTIVE DATE: 06/19/2020 SUPERCEDES: 01/07/2020