

BALCONYGUARD™ OUTSIDE CORNER BOOT

Product Data Sheet

Waterproofing Accessory

PRODUCT NAME

Balconyguard™ Outside Corner Boot

can vary depending on the system specified by Polyguard, so contact Polyguard for additional information.

MANUFACTURER

Polyguard Products, Inc.
Ennis, TX 75119
(214) 515-5000
www.polyguard.com

LIMITATIONS

Cover Polyguard Membranes within thirty (30) days to prevent prolonged exposure to sunlight.

PRODUCT DESCRIPTION

BASIC USES

The Balconyguard™ Outside Corner Boot is a 60-mil combination of rubberized asphalt and polyethylene. The adhesive surface is covered with a release liner to be removed prior to application of the Balconyguard Membrane.

STORAGE

Polyguard Membranes should be handled and stored so as to prevent injury to packages. Material should be stored in a cool, dry place, kept from contact with earth and protected from weather. Materials should be stored in heated buildings during cold weather.

The Balconyguard™ Outside Corner Boot is applied to the outside face of the balcony at the wall-to-balcony interface.

SAFETY

SDS documents for all Polyguard products can be obtained at our website www.polyguard.com. Call Polyguard Products, Inc. at (214) 515-5000 with questions.

The Balconyguard™ Outside Corner Boot can also be used with PRM and 650 Membrane waterproofing systems.

WARRANTY

We, the manufacturer, warrant only that this product is free of defects, since many factors which affect the results obtained from this product are beyond our control; such as weather, workmanship, equipment utilized, and prior condition of the substrate. We will replace, at no charge, proven defective product within twelve (12) months of purchase, provided it has been applied in accordance with our written directions for uses we recommended as suitable for this product. Proof of purchase must be provided. A five (5) year material or system warranty may be available upon request. Contact Polyguard Products, Inc. for further details.

INSTALLATION

SURFACE PREPARATION

Balconyguard™ Outside Corner Boot film side must be clean, dry, and free of contaminants, prior to applying Balconyguard Membrane over the boot and wall-to-balcony flashing.

TECHNICAL SERVICES

Technical assistance, information and Polyguard's products are available through a nationwide network of distributors and architectural representatives, or contact Polyguard Products, Inc.
P.O. Box 755, Ennis, TX 75120-0755
Sales: (615) 217-6061 • Tech Support: (214) 515-5000
Email: archtech@polyguard.com
Website: www.polyguard.com

The wall and balcony surfaces must be clean, dry, and primed with Polyguard-approved adhesive according to Polyguard's specifications and recommendations prior to application of Balconyguard materials.

APPLICATION

Place the corner boot with the adhesive side to face the inside of the wall-to-balcony outside face transition. Apply the Balconyguard™ Membrane as per installation instruction. Press the adhesive side of the Balconyguard Membrane onto the exposed film of the Balconyguard™ Outside Corner Boot. Application method and substrate

PACKAGING	PART NUMBER	UNIT SIZE
BALCONYGUARD™ OUTSIDE CORNER BOOT 6" X 6" X 6"	PREFABRICATED 6" CORNER BOOTS	25 pcs/ctn
BALCONYGUARD™ MEMBRANE	BALCONY GUARD 48	48" x 50' roll
105-12 FLASHING	10512	12" x 50' rolls (2/ctn)