



BLINDSIDE MEMBRANE FABRIC FACING CONCRETE POUR OR SHOTCRETE WHEN NOT IN WATER TABLE - IF IN WATER TABLE CONSULT POLYGUARD - APPLIED BEHIND EXISTING BLINDSIDE SHEET A MAXIMUM 4"

COVERING BEAD OF DETAIL SEALANT PW OR LM-95 APPLIED TO FABRIC OF BLINDSIDE MEMBRANE. PREPARE FABRIC BEING COVERED WITH 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT AT A RATE OF 50 - 75 SF/GAL

APPLY FASTENERS AT NOT GREATER THAN 12" SPACING AFTER SECOND LIFT IS IN PLACE

12" STRIP OF FABRIC TAPE CENTERED AND ADHERED ACROSS THE ENDLAP SEAM - EXTEND TO 6" BEYOND EACH SIDE SEAM OF ENDLAP - PREPARE FABRIC BEING COVERED WITH 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT APPLIED AT A RATE OF 50 - 75 SF/GAL

APPLY FASTENERS NOT GREATER THAN 12" SPACING TO HOLD BLINDSIDE IN PLACE PRIOR TO SECOND LIFT PLACEMENT

BLINDSIDE MEMBRANE FABRIC FACING CONCRETE POUR - FOLD BACK A MAXIMUM OF 4" FLAP AND PROTECT UNTIL PLACEMENT OF NEXT SHEET OF BLINDSIDE MEMBRANE SHEET

BS7

SECTION@ BLINDSIDE MEMBRANE END LAP

© POLYGUARD PRODUCTS, INC.
MATERIALS SEPARATED FOR CLARITY

<p>The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.</p>	NOT TO SCALE
	EFFECTIVE DATE: 03/05/2021
	SUPERCEDES: 05/22/2019