

## US OUTSIDE CORNER BOOT

Waterproofing Accessory

## Product Data Sheet

### PRODUCT NAME

US Outside Corner Boot

depending on the system specified by Polyguard, so contact Polyguard for additional information.

### MANUFACTURER

Polyguard Products, Inc.  
Ennis, TX 75119  
(214) 515-5000  
[www.polyguard.com](http://www.polyguard.com)

### LIMITATIONS

Cover Polyguard Membranes within thirty (30) days to prevent prolonged exposure to sunlight.

### PRODUCT DESCRIPTION

#### BASIC USES

The US Outside Corner Boot is a 60-mil combination of rubberized asphalt bonded to polyethylene. The adhesive surface is covered with a release liner which will be removed prior to application of Underseal® Underslab Membrane.

### STORAGE

Polyguard membranes should be handled and stored so as to prevent injury to packages. Material should be stored in a cool, dry place, kept from contact with earth and protected from weather. Materials should be stored in heated buildings during cold weather.

Apply US Outside Corner Boot on the outside corner to reinforce and seal the Underslab Membrane. Use US Outside Corner Boots at all outside corners.

### SAFETY

SDS documents for all Polyguard products can be obtained at our website [www.polyguard.com](http://www.polyguard.com). Call Polyguard Products, Inc. at (214) 515-5000 with questions.

Underslab Membrane corners require a series of cuts, folds, flaps, and patching with LM-95 or Detail Sealant PW, which can leave a pinhole in the corner. This preformed corner boot conforms to the film side of the Underslab Membrane to seal any possible pinhole condition.

### WARRANTY

We, the manufacturer, warrant only that this product is free of defects, since many factors which affect the results obtained from this product are beyond our control; such as weather, workmanship, equipment utilized, and prior condition of the substrate. We will replace, at no charge, proven defective product within twelve (12) months of purchase, provided it has been applied in accordance with our written directions for uses we recommended as suitable for this product. Proof of purchase must be provided. A five (5) year material or system warranty may be available upon request. Contact Polyguard Products, Inc. for further details.

### ISO 9001 QUALITY CERIFICATION

US Outside Corner Boots are not covered by Polyguard's ISO 9001 quality system.

### INSTALLATION

#### SURFACE PREPARATION

Film side of the Underslab Membrane must be clean, dry, and free of contaminants, prior to applying over US Outside Corner Boot.

### TECHNICAL SERVICES

Technical assistance, information and Polyguard's products are available through a nationwide network of distributors and architectural representatives, or contact Polyguard Products, Inc.

#### APPLICATION

Place the US Outside Corner Boot with film side to the inside of the forms; remove release liner thereby exposing the asphalt adhesive. Apply the Underslab Membrane as per installation instruction. Press the film of the Underslab Membrane into the exposed asphalt of the US Outside Corner Boot. Application method and substrate can vary

P.O. Box 755, Ennis, TX 75120-0755  
Sales: (615) 217-6061 • Tech Support: (214) 515-5000 • Fax: (615) 691-5500  
Email: [archtech@polyguard.com](mailto:archtech@polyguard.com)  
Website: [www.polyguard.com](http://www.polyguard.com)

PACKAGING	PART NUMBER	UNIT SIZE
US INSIDE CORNER BOOT 12" X 12" X 12"	US 12" INSIDE CORNER BOOT	25 pcs/ctn
US OUTSIDE CORNER BOOT 12" X 12" X 6"	US OUTSIDE CORNER BOOT 12"	25 pcs/ctn
US PIT TOP CORNER BOOT 6" X 6" X 6"	PREFABRICATED 6" CORNER BOOTS	25 pcs/ctn
BLINDSIDE™ - 73 MILS	751	48" x 50' roll
UNDERSLAB - 85 MILS	850	48" x 50' roll
PRM™	851	49" x 49' roll