



1. Cut 2 - 12" x 18" pieces of 650 or Balconyguard Membrane -
A. A & B piece cut to dimensions above and mirror image
2. Score 3/4" - 1" release film at angled edge - remove the film
3. Adhere piece A and B at exposed 3/4" - 1" compound - roll tight

US24

FIELD MADE OUTSIDE CORNER BOOT DETAIL

© POLYGUARD PRODUCTS, INC.