

## Installation Instructions for Geowrap®

Geowrap® is used as an outerwrap over RG2400® products to support the RG on large diameter hot pipes which may vibrate and/or to keep the insulation clean when future inspection may be desired. Geowrap is available in 12" and 48" by 400 LF rolls.

Install Geowrap as follows:

1. RG corrosion gel should be installed on pipe per written instructions from Polyguard;
2. Geowrap should be cut in sections to fit the outer circumference of the pipe allowing for a minimum overlap of 1" on the longitudinal edge;
3. Geowrap should then be wrapped around the pipe and gently pressed into the RG being careful not to wrinkle or crease the material;
4. The next section of Geowrap should then be installed allowing for a minimum overlap of 2" on the circumferential edge;
5. All edges can be taped, as an option, using either a 2mil foil or FSK tape;
6. Insulation should be installed over the Geowrap using care not to displace the Geowrap and RG below.

*X:/PGP/Mktg/Lit/Mech/Geowrap Installation Instructions R6-17-19.doc*